



GolfSim Designer Cut Series

ImpactWhite™ 1145 Sport Simulation Projection Material

For models: RM-10X10-IP1145 / RM10X13-IPW1145

Care & Use

Elite Screens wants you to enjoy your **Designer Cut Golf Impact Projection Screen** to its full extent and for many years to come! We made the Designer Cut materials available for you to be able to fully customize your projection experience, however, please note that ALL Designer Cut materials do require specific properties to be adhered during installation to obtain an enjoyable viewing experience.

The **GolfSim Designer Cut** is a pre-cut **ImpactWhite 1145™** golf screen material. ImpactWhite 1145™ is a three-layer tightly weaved fabric designed to provide exceptional projection imaging characteristics with the ability to also perform as a Golf Impact Screen.

| ImpactWhite™320 Designer Cut Specifications | |
|---|------------------------|
| Color | White |
| Thickness | 4.5 mm |
| Material composition | 100% Polyester |
| Weight | 1145 g /m ² |
| Gain | 0.8 |
| Viewing Angle | 180° |

Installation Tips and Precautions

1. Make sure to use the correct side. The ImpactWhite™ 1145 screen should have a front and back label.
2. Wear gloves and unroll the material on a clean surface.
3. Handle with caution, material is subject to static electricity.
4. Folding lines/wrinkles are normal due to the nature of the material structure and packaging.
5. Make sure to allow proper distance for swing range to protect children, pets, ceilings, walls, windows, or any other property.
6. Avoid using golf balls with scuffs or markings to maximize the life of your ImpactWhite™ 1145 screen. If possible, use new golf balls.
7. Never place the screen over a window or under constant sun exposure. Solar radiation from direct sunlight destroys the synthetic fibers of the screen.

Maintenance

- Use a soft bristle brush or dry microfiber cloth to remove dust from the screen surface.
- When cleaning, use a microfiber cloth dampened with warm water to remove any traces.
- Use a fabric steamer to remove any wrinkles or folds in the material.
- Do NOT rub or apply pressure when cleaning the surface.
- Do NOT use any solutions, chemicals, or abrasive cleaners onto the screen surface.
- DO NOT touch the screen directly with your fingers, pens/pencils or any other sharp or abrasive objects.

We take great care in packaging the Designer Cut series of materials so that they arrive at your doorstep with zero issues. Should your screen arrive with any shipping damage or show signs of damage, we urge you to contact us directly so that we can provide a speedy resolution – we always strive for the best customer experience and are here to help.

**For Technical Support or an Elite Screens contact in your area,
visit www.elitescreens.com**