

AcousticPro 1080P3

Acoustically Transparent Projection Material

Care & Use

Proper care and use of the **AcousticPro1080P3** will maximize the life of the material to bring you years of enjoyment.

Projection Side

The AcousticPro 1080P3 material has a very similar look on both sides. Please take note of the label on the material. It will be labeled front side or projection side.

NOTE: The AcousticPro 1080P3 material may require sound transparent backing to reduce projection reflectivity depending on your DIY project. Speaker fabric or dark colored mesh fabric is highly recommended and readily available at most fabric stores.



Material Maintenance

Wrinkles/Creases:

The material may have minor wrinkles which will get removed after stretching it over a frame or a mounting system that allows tensioning. You can also use a handheld fabric steamer to remove wrinkles or creases.

Dust/Dirt:

A feather duster should be used to remove loose dirt or dust. Use warm water with a toothbrush to clean dirt or dust spots. Do not use soap as it will stain the material.

Quick Tip

For best picture quality results, maintain a minimum viewing distance if possible 1.5 times the width of your projection image.

For more information, visit www.elitescreens.com

