ZFE-RT Installation & Control Instructions

A.
IR Remote

B.
RF Remote

C.
3- way Wall Switch

55"

Green -   Red+

D.
12V Trigger

E.
IR ey receiver

110"

RJ45 port

F. Wall box

1. Disconnect the 3 Way Control Switch from the Kestrel Stage Screen as shown below.

3 Way Control Switch

Screen

Kestrel Stage Screen

2. Connect the **Wall Box (F)** to the screen as shown below.

Kestrel Stage Screen

3. After connecting the wall box to the screen, you can operate the screen with the IR, RF remote control or the 3-way wall switch.

RF remote – Does not require line of sight for operation. Just press the UP button to raise the screen and the DOWN button to retract screen.

IR remote – Requires line of sight and the IR "eye" sensor to be connected to the Wall Box's RJ45 port

3-way wall switch – Manually control the screens DOWN, STOP, and UP operation by connectin the switch to the RJ45 port.