



# **Aeon AcousticPro UHD Series**



*EDGE FREE® Fixed Frame  
Sound Transparent Projection Screen  
User's Guide*

## **Product Description:**

The **Aeon AcousticPro UHD** Series is a fixed frame projection screen that uses Elite's EDGE FREE® technology. The EDGE FREE® design resembles a giant size flat panel TV display. The **Aeon** includes Edge trim as an installation option to further enhance the frame appearance and absorb projector overshoot.

## **Maintenance and Care**




















In order for the **AcousticPro UHD** material to maintain its projection qualities and provide optimum performance please refer to the list below for proper maintenance and cleaning.

**The following precautions should always be taken to avoid damaging the material which is not covered under the warranty.**

- Use a dry microfiber cloth or a soft bristle brush to remove dust from the screen's surface.
- When cleaning the surface, use a damp microfiber cloth with warm water and never rub or apply pressure.
- Never attempt to use any chemicals such as acetone, benzene, alcohol, organic solvents or abrasive cleaners to clean the screen surface.
- To avoid damaging the screen, avoid touching it directly with your fingers, pens/pencils or any other sharp or abrasive objects.


## Hardware and Parts List

Please make sure all parts listed below are included before installation.


<p><b>A. Elbow Joint x 4 pcs</b></p>	<p><b>B. Top/Bottom Horizontal Frame x 4 pcs</b></p>	<p><b>C. Left/Right Vertical Frame x 2 pcs</b></p>	<p><b>D. Center Joints x 2 pcs</b></p>
			
<p><b>E. Center Support Bar x 2-4 pcs</b></p>	<p><b>F. Wall brackets x 4 -6 pcs</b></p>	<p><b>G. M5x6 screw x 24 pcs</b></p>	<p><b>H. M4x32 screws and anchors x 6-9 pcs</b></p>
			
<p><b>I. Tension rods x 6 pcs</b></p>	<p><b>J. Screwdriver x 1 pc</b></p>	<p><b>K. Black Tape x 1 bag</b></p>	<p><b>L. Bezel trim x 6 pcs</b></p>
			
	<p><b>N. Spring x 50 ~ 200 pcs</b></p>	<p><b>O. Hook x 2 pcs</b></p>	<p><b>P. Corner sleeve x 4 pcs</b></p>
	<p>(Iron color)</p>		
<p><b>Q. Gloves x 2 pair</b></p>	<p><b>R. Protection sheet x 1 pc</b></p>	<p><b>S. Screen material x 1-2 pcs</b></p>	<p><b>T. Trim Spring x 12 pcs</b></p>
			<p>(Black color)</p> 

## Frame Assembly


1. Insert the center joint into one of the  $\frac{1}{2}$  *Horizontal Frames (B)* and fasten it with the two *M5x6 screws (G)*.
2. Insert the other  $\frac{1}{2}$  horizontal frame piece to the *Center Joint (D)* and fasten also using two *M5x6 screws*.
3. Repeat steps 1 and 2 for assembling the second horizontal frame.



4. Insert the *elbow joint (A)* into each end of the *horizontal frames (B)* as shown below.





5. Insert the two *vertical short frames (C)* into the *elbow joint (A)*.






6. Join the remaining **horizontal long frame (B)** with the frame built in the previous steps as shown below.



7. Make sure all four corners are properly in place to form a perfect square. Then fasten the four angles with the **M5x6 Screws (G)**.



**Support bar installation (for models under 180", not including 180")**

1. Position the *center support bar (E)* to the area of the frame shown in figure 1. Align the hole on each end of the support bar with the *M6 hex screws* on the top and bottom frames. Then fasten with the *M6x12 screws*.






Figure 1




※ For model over 180" (Including 180"), using 4 support bars




## Black Backing Cloth Installation

1. Lay the black backing cloth on the protective sheet, then put the fully assembled frame on the black backing cloth with the **Velcro part facing up**.




2. Fold back the black backing cloth to the back of the frame and attach the four corners to the Velcro on the frame in the following sequence 1→2→3→4. Smooth it out with your hands to assure a tight finish and no wrinkles are present. **IMPORTANT: The four sides of the black backing cloth should not be out of the Velcro range.**



3. Continue attaching the remaining black cloth to the velcro in the following sequence 5→6→7→8 to finish installation. Smooth it out with your hands to assure a tight finish and no wrinkles are present.

**IMPORTANT: The remaining sides of the black backing cloth should not be out of the Velcro range.**





## Screen Material Installation


1. Make sure the screen material and frame are both lying face down on a clean, dry, and non-abrasive **Protection Sheet (S)** and please wear installation **Gloves (Q)** before install screen material. (Fig.1)

This is to avoid leaving oily handprints on the screen surface which are not removable.

2. Remove the screen material from the tube and place a small suitable weighted object at the end of the material. (Fig.2)
3. Lay the material face down, two people carefully lift the rolled end and slowly rotate the material clockwise. (Fig.3)




4. Insert the corresponding **Tension rods (I)** on thru the sleeves on the edges of the material. (Rod 1/2 insert to the short frame, rod 3/4/5/6 insert to the long frame) (Fig.4)



- Carefully and gently place the assembled frame on top of the screen material, adjust the distance between the frame edge and the material to be the same. (Fig.5)


DO NOT allow the angle edge of the frame to come in direct contact with the material to avoid puncturing it.




(Fig.5)

- Begin by simultaneously attaching four springs in the center of the side frames (A→B→C→D). (Fig.6)

Spring Attachment Metho: First hook one end of the spring in the frame slot, then hold the screen around the frame to pull, and finally use the spring hook to pull the spring in the tension rod of screen hole. (Fig.7)




(Fig.6)



(Fig.7)

7. Install the spring at point 1 first, then install the spring at point 2, and finally install the remaining springs.

(Fig.8)



(Fig.8)


**Edge trim Installation**

Included is an ultra-thin black edge trim that provides an elegant bezel finish


Edge trim (L) x 6 pcs



Corner sleeve (P) x 4 pcs




Trim spring (T) x 12 pcs




Black tape (K) x 1 pcs



1. Place the assembled frame on a flat and clean surface. The projection screen surface should be “facing down”.
2. Place all the trim pieces along the edge of screen material. Adjust the trim so that the top and bottom trim pieces are touching and show no gaps in the center. (Note: The Elite logo should be positioned on the bottom right). Refer to Figure 9 below for a visual reference.






(Fig.9)






**TIP:**  
Align the trim starting from the center to reduce gapping. Any gaps left at the corners will be covered by the corner sleeves.

3. Attach Trim Spring (T) on each edge trim to the frame as shown below image.
  - ※ Please note that trim spring has different lengths of side, short side is for frame, long side is for edge trim.
  - ※ Each edge trim uses 2 trim spring to install, refer the position as below image.




As an option, Black Tape is supplied to cover any possible gaps between the pieces of the bezel trim. Align the tape with the edge of the screen, as shown in Figure 10. Once properly aligned, apply the black tape to the center of the top and bottom of the screen material.



 **NOTE:** Make sure the bottom edge trim with the Elite Screens logo is installed on the correct side. The back of the material should be labeled with a **BOTTOM** sticker to indicate the material is facing in the down position. The Elite Screens logo should be installed on the **DOWN** side

- After the bezel trim has been installed, place a **Corner sleeve (P)** on all four corners. Begin by aligning and adjusting the corner sleeve through the front of the screen. Make sure the corner sleeve completely wraps the edge of the bezel trim. This should cover any corner gaps.




Once all corner sleeves have been snapped into each corner of the frame, it is ready to be installed.

## Installation


Locate your desired installation location with a stud finder (recommended) and mark the drill-hole area of where the screen is to be installed.

1. Drill a hole with the proper bit size according to the wood screws included.
  2. Line up the wall brackets with the drilled holes on the installation location and screw them in using a Phillips screwdriver.
  3. Position the frame screen onto the **wall brackets (F)** as shown in **below**.
  4. The design of the wall brackets allows the frame to slide over them through its sides. This is an important feature of the installation design as it allows your screen to be properly centered.
- ✘ Please calculate according to the algorithm:  
H = Frame height - 170 mm  
L = Frame width - (1000 mm ~ 600 mm)



## Hanging the screen:

1. Two people hold the screen and align it first with the bottom bracket. The bracket lip must be inserted in the frame's channel per example below.
2. Then pull up the screen on the top bracket and adjust the screen left to right as needed.



**For a local Elite Screens contact or Technical Support, please visit**

[www.elitescreens.com](http://www.elitescreens.com)